



Triad Audio Matrix ELAN Driver

V1.0 rev20190815

Overview

This driver integrates a Triad AMS8 or AMS24 Audio Matrix into your ELAN control system. The driver was created and tested on a gSC2 series controller using g!Viewer. To use this driver, add the driver to the system, and follow the setup.

Change Log

V1.0

Release

Specification

This package includes the following:

- Compiled ELAN Driver (TriadAMS8AMS24AudioMatrix.EDRVC)
 - Controls hardware device.

IP Connection

The driver communicates to and from the device through an IP connection and must be connected for the driver to function. Please note that certain features will not be populated depending on the piece of hardware used.

Setup

1. Add the driver as a media zone controller. Enter the IP Address of the Triad unit and hit apply. The driver will connect and initialize the current state of the unit.
2. Configure sources and zones.
3. Test to ensure unit is controllable.



ELAN[®]
Developer Partners



Snap av